



WHEEL FIT UP BOLTS UNIVERSAL



Problem: Brake disc VW-Group, without centering screw in the brake disc – free turning



Problem: Extremely short hub edge – Danger of falling wheel!



Hub edge

Problem: huge and heavy aluminium wheels



Pin for wheel support

- Especially dedicated for cars with short axle tie free turning brake disc without centering screw.
- Just stick the bolts in to the wheel bolt bolts.
- Very quick mounting without any thread.
- For wheel bolts M12 and M14.

GO	CODE	038
1	with 7 pcs.	kg 0,3 kg



SPECIAL SOCKET SET 1, FOR DAMAGED FORD WHEEL NUTS

NEW



Components

- 1 x 1/2" wheel impact socket, 18.5 mm, Grey
- 1 x 1/2" wheel impact socket, 19.5 mm, Orange



PLUS:

After repeated wheel changes, the sheet metal caps can become damaged, meaning that standard socket sizes no longer fit correctly. **The special sizes included in this set ensure smooth and trouble-free wheel changes.**

Components

- 1 x 1/2" wheel impact socket, 20.5 mm, Black
- 1 x 1/2" wheel impact socket, 21.5 mm, Purple



- Ideal for damaged Ford wheel nuts with sheet metal caps.

GO	CODE	026
1	with 2 pcs.	kg 0,5 kg

Technical data

- Length: 85mm
- Chrome molybdenum steel
- Suitable for 1/2" impact wrenches

- Protects both the wheel nut and the wheel
- Plastic sleeve and protective insert
- Colour-coded by socket size

GO	CODE	027
1	with 2 pcs.	kg 0,5 kg