



BOSCH CR INJECTOR EXTRACTOR KIT - BASIC




INCLUDED:

Lubricating grease to be used with threaded bars, nuts etc...

Application

The set allows you to adapt about 90% of all injectors.

- This set is required as a base for traditional injector disassembly tools, such as the slide hammer or the injector bridge.
- It contains all the tools needed to breakdown the piece and the adapters for screws needed for connection to the disassembly system available.
- In this way the injectors can then be extracted with high impact and hydraulic forces.



INJECTOR ADAPTOR SET - BOSCH



Components

- | | | |
|---|---|---|
| 1 | x | Screw M18x1.5 l=220 mm |
| 1 | x | Washer with bearing |
| 1 | x | Extension FF M18x1.5 |
| 1 | x | Adapter Int. M17x1 - Ext. M27x1 (BOSCH) |
| 1 | x | Nut M18x1.5 - CH30 |

- Integrative set for the extraction of Bosch CR injector.
- For engines where it is necessary a double and simultaneous extraction of the injectors.



CODE

414

1 with 26 pcs.

kg 12 kg

§ **PATENTED**



CODE

421

1 with 5 pcs.

kg 1,4 kg